

Connecting Epic WiFi to Your iOS Device

(iPad, iPod Touch and iPhone)

1. Turn on your iOS device
2. Check your internet  make sure you are connected
3. Click on APP STORE icon 
4. Click on the SEARCH icon on the top right 
5. Type "CentroControl" in search box 
6. Click the GET button 

Installing Custom Controls

1. Click SETTINGS Icon  on your iOS Device and scroll down to find Centro Control
2. Click on Centro Control icon 
3. Under ADVANCED click "Project Setup"

Set the following options:

Reload next time?

Reload images/sound?

Project Location: http://epixskydownloads.com/YOUR-PROJECT*

***Project Name:** *(This is name is custom to your job. You should have received custom instructions in your delivery. If you DID NOT Receive your instructions call 800-507-5714 and ask for technical support. Please have with your job number ready so we can pull up your program immediately)*

**** make sure all other options are OFF ****

4. Exit Settings and launch CENTRO CONTROL App. 

Once the program has completed downloading and the control screen appears, exit app.

1. Click SETTINGS 
 2. Click on GENERAL
 3. Scroll to CENTRO CONTROL App
 4. Navigate to PROJECT SETUP click "Project Setup"
- Set the following options:

Reload next time?

Reload images/sound?

4. On left margin click on Wi-Fi 
6. On right margin click on the project WiFi Interface (Default is "Epic WiFi")